# VVDI2 – Install Software and Driver





# **Table of Contents**

1.	Document Declaration	 3
2	Install software	1
۷.	Ilistali software	 4
3.	Install Driver	 8
	3.1. Manual Install Driver	8



### 1. Document Declaration

Please view the following declaration carefully:

- ◆ VVDI2 Install Software and Driver can help you install software and VVDI2 driver. Please DON'T used for illegal purpose, Please follow the national law
- ◆ VVDI2 Install Software and Driver is written by VVDI2, please DON'T used for commercial purposes without authorize
- ◆ Install driver and set latency timer is very important, please view carefully
- ♠ Any illegal use VVDI2 Install Software and Driver, illegal use VVDI2 device, The user should take all risks, the company does not assume any responsibility



## 2.Install software

Install software is very easy, just follow the window. Show with window steps:



1) Double click install programs:




2) Choose install language:



3)





Begin installation of VVDI2

Click Install to begin the installation. If you want to review or change any of your installation settings, click Back. Close the window to exit the wizard.

OBD2GATE .com

4)




Attention: If you are install VVDI2 software (any version) for first time, you need choose NEXT, else you can choose CANCEL



OBD2GATE Com

7)



Install complete. There will be a quick start on your desktop




#### 3. Install Driver

- ◆ Generally, VVDI2 driver can install automatically with install software.
- ◆ If install driver failed or your programs can not connect to VVDI2, you need manual install driver accord chapter 3.1


#### 3.1. Manual Install Driver

◆ Open Device Manager: Open windows explorer, right click "My computer" and select "Properties" (PICTURE 3. 1), open "System properties" (PICTURE 3. 2), select "Hardware" -> "Device Manager", Open Device Manager (PICTURE 3. 3)




(PICTURE 3. 1)





(PICTURE 3. 2)






(PICTURE 3. 3)

- ◆ Install bus driver: Disconnect other USB cable from PC(Mouse and keyboard should keep connect)
  - > VVDI2 install with other version drivers: In (PICTURE 3.3) select "Universal Serial Bus controllers" -> "USB Serial Converter", double click on it, get properties window(PICTURE 3.4)
    - View "**Driver**" page: "**Driver Date**" should be: **3/18/2011**, "**Driver Version**" should be: **2.8.14.0**(**PICTURE 3.11**). If all right, don't install driver again. If not shown as before, you need install driver with following steps:
    - 1) In (<u>PICTURE 3.4</u>), select "**Driver**" -> "**Update Driver**". Open "Hardware Update Wizard" (<u>PICTURE 3.5</u>)
    - 2) In (<u>PICTURE 3.5</u>), select "Install from a list or specific location (Advanced)", next to get window (<u>PICTURE 3.6</u>)
    - 3) In (<u>PICTURE 3.6</u>), select "**Don't' search. I will choose the driver to install.**" next to get window (<u>PICTURE 3.7</u>). Sometimes you will get (<u>PICTURE 3.8</u>) directly, at this situation, go to step 5)
    - 4) In (<u>PICTURE 3.7)</u>, select "**Universal Serial Bus controllers**", next to get window (<u>PICTURE 3.8</u>)




- 5) In (PICTURE 3.8), select "Have Disk...", get install from disk window (PICTURE 3.9)
- 6) In (PICTURE 3.9), input absolute path for USB Driver folder in install directory (Browse... and choose install directory, or you can find the path from Start->Programs->VVDI2->USB Drivers). Press OK and wait complete. Sometimes system will ask again for Are you sure to install this driver? Continue is need




(PICTURE 3. 4)






(PICTURE 3. 5)




(PICTURE 3. 6)





(PICTURE 3. 7)




(PICTURE 3.8)





(PICTURE 3. 9)


> VVDI2 is not recognized: you can find VVDI2(with yellow!) in "Other devices" list from device manager (PICTURE 3.10), double click get properties window. Then install driver accord VVDI2 install with other version drivers



(PICTURE 3.10)



◆ Verify Bus Driver: Open properties window after install driver, view Driver page: "Driver Date" should be: 3/18/2011, "Driver Version" should be: 2.8.14.0(PICTURE 3.11)



(PICTURE 3. 11)

